

# Connecting with *InPhonex* service

*InPhonex* (<http://www.inphonex.com>) is a VoIP service company founded in 2003, with its voice and data network based in Miami, Florida, USA. Besides making/receiving VoIP calls to/from VoIP telephone numbers and making VoIP calls to PSTN telephone numbers, *InPhonex* provides an option for you to have real Miami telephone number (DID) to receive PSTN calls from anyone. This document will explain how to utilize OnDO PBX with *InPhonex*.

<b>1.</b>	<b>SETTING UP AN <i>INPHONEX</i> ACCOUNT.....</b>	<b>2</b>
<b>2.</b>	<b>ARS CONFIGURATION FOR <i>INPHONEX</i>.....</b>	<b>2</b>
2.1.	General Settings.....	3
2.2.	Pattern Settings.....	3
2.2.1.	Incoming call pattern.....	3
2.2.2.	Outgoing call pattern.....	4
2.2.3.	Priorities.....	4
<b>3.</b>	<b>ONDO SIP SERVER DIAL PLAN SETTINGS .....</b>	<b>5</b>
<b>4.</b>	<b>NOTES FOR DIAL PLAN SETTINGS.....</b>	<b>5</b>

## 1. Setting up an *InPhonex* account

Please obtain an account from *InPhonex* website.

<b>PSTN telephone number</b>	1305#####
<b>Server Name</b>	sip.inphonex.com
<b>User ID/number</b>	7770003 (example)
<b>Password</b>	*****

## 2. ARS Configuration for *InPhonex*

To define ARS settings for your *InPhonex* account:

- 1) Choose **[ARS]** in the OnDO PBX Admintool.
- 2) Type a route name in the entry field (we suggest *InPhonex*)
- 3) Click **[Create a new route]**. Your new route will appear in the list above.
- 4) Click the **[Edit]** button next to your new route to define conditions.

For more information on ARS settings, please refer to the OnDO PBX Administrator's Guide.

Please see the following sections of this document for ARS settings relevant to *InPhonex* service.

## 2.1. General Settings

<b>Register URI</b>	sip:7770003@sip.inphonex.com
<b>Realm</b>	
<b>Proxy Address</b>	sip.inphonex.com
<b>User ID/Number</b>	7770003
<b>Password</b>	*****

In the **[Register URI]** field, enter your *InPhonex* user ID/number and the server name in the format shown above. Enter the server/proxy address, your User ID/number and password as assigned by *InPhonex* in the appropriate fields.

## 2.2. Pattern Settings

### 2.2.1. Incoming call pattern

<b>Direction</b>	IN
<b>Matching patterns: From</b>	
<b>Matching patterns: To</b>	sip:7770003@
<b>Deploy patterns: From</b>	
<b>Deploy patterns: To</b>	OnDO PBX extension number
<b>Ignore Priorities smaller than No.</b>	1
<b>Deploy patterns: DTMF</b>	
<b>RTP relay</b>	on(G.711u only)

To direct incoming calls from PSTN callers or VoIP callers, enter your user ID/number in the **[Matching patterns: To]** field, in the format shown above. All calls terminated on your user ID/number will be directed to the extension set in the **[Deploy patterns: To]** field.

## 2.2.2. Outgoing call pattern

<b>Direction</b>	OUT
<b>Matching patterns: From</b>	
<b>Matching patterns: To</b>	sip:9(.+)
<b>Deploy patterns: From</b>	"7770003"<sip:7770003@sip.inphonex.com>
<b>Deploy patterns: To</b>	sip:\$1@sip.inphonex.com
<b>Ignore Priorities small than No.</b>	1
<b>Deploy patterns: DTMF</b>	
<b>RTP relay</b>	on(G.711u only)

This rule handles calls made by OnDO PBX users via the ITSP: dialing 9 first to call places outside of the PBX. In the **[Matching patterns: To]** field, "9" represents the dialing prefix, and (.+) represents any number of dialing digits. The **[Deploy patterns: To]** will automatically remove the prefix, 9, from all outgoing calls.

## 2.2.3. Priorities

<b>Direction</b>	IN/OUT
<b>Max sessions</b>	-1
<b>Priorities</b>	100

Here, all priority settings have been left at their respective default values. To give this rule a higher priority, set its Priority to a number with a lesser value. In the **[Max sessions]** field, -1 indicates an unlimited amount.

### 3. OnDO SIP Server Dial Plan Settings

Dial Plan can accommodate the unique requirements of each VoIP service provider.

Receiving calls to an *InPhonex* number

Matching Patterns	Deploy Patterns
\$addr=^208\.239\.76\.145	\$target=localhost:15060
\$request=^INVITE	To=%1
to=(.*)	\$auth=off

✓ This Dial Plan needs to be placed before "to PBX" (default dial plan).

### 4. Notes for Dial Plan settings

- ◆ This Dial Plan allows calls from the *InPhonex* line to pass through without authentication from OnDO SIP Server. When INVITE authentication is tuned off at [Config] menu in OnDO SIP Server, this Dial Plan setting can be omitted.
- ◆ Note that you may need to update Dial Plan rules that include *InPhonex*'s SIP Server IP address. *InPhonex* may change their Server's IP address at any time.
- ◆ In this tutorial guide, [RTP relay] is set for "on" in ARS deploy pattern setting. In some cases, setting [RTP relay] = "off" may work; however, we have not tested all of the applicable environments.